

USER MANUAL FOR OIL LAMPS

FUNCTIONAL DESCRIPTION

The oil lamp is composed of a container where the lamp oil is poured and stored, a burner and its wick, and a closing cap; it can be made of porcelain, glass, or metal.

PURPOSE OF USE

The oil lamp can only be used in the professional liturgical field.

WARNING: ANY OTHER USE IS STRICTLY PROHIBITED.

It is forbidden:

- The use by non-experts and children
- The use of the lamp in fields other than the professional liturgical
- Any use of the lamp other than what said in the present document
- To tamper with the lamp
- To replace any part of the lamp with not suitable parts
- To modify the lamp adding parts that change its functioning
- To use oil different from that suggested by the manufacturer
- To use the lamp in case of breakage of any part

Remember to never leave the lamp unattended, neither switched on nor off, in order to avoid accidental falls or any other accident.

After its use, remember to switch off the oil lamp and put it away in a secure place, away from children.

If unused in a long time, the lamp must be put away after emptying its container, so that no oil remains inside it.

TYPE AND PLACING OF THE WICK

The wick is made of a porous material (so it can soak in oil) and is placed inside the container; one of the two ends comes out from the burner and the cap so it can ignite.

RECOMMENDED HEIGHT

The wick must come out of the cap for a maximum length of 2/3mm, so that igniting it is possible.

RECOMMENDED OIL FUEL

The recommended fuel product for the oil lamp is "CERA DELL'EREMO"; the "LUX MUNDI" product can also be used. The data sheets of the above-mentioned products are available to the user, upon demand to the manufacturer.

WARNING: the use of other oils or fuel products is strongly discouraged. The manufacturer assumes no responsibility on the use of any product other from those above-mentioned.

FILLING THE CONTAINER, OPENING MECHANISM AND QUANTITY

To ease the positioning of the wick and to avoid oil spills, the lamp container must be filled for 3/4 of its volume.

It is necessary to place the oil lamp in a good position: because of the flame, it's mandatory to place it away from children and pets, to avoid accidental overturns and falls of the lamp.

After filling the container, the cap must be installed, so that it's fixed on tight. It's also necessary to wait for the wick to soak well before turning the lamp on.

MAINTENANCE OF BURNER AND WICK

After a couple hours of use, every part of the lamp has to be examined to verify there are no functional changes; in particular the burner and the wick must be well inspected since they must remain undamaged for the whole life of the lamp.

INSTRUCTIONS ON THE LAMP'S LABEL



A label reporting barcode and manufacturer's info is placed on the lamp.

The following security and use warnings are also reported:

WARNING: DON'T INGEST THE OIL CONTAINED INSIDE, LIFE HAZARD
IF INGESTED IMMEDIATELY SEEK MEDICAL HELP AND DON'T INDUCE VOMIT
WARNING: FLAMMABLE LIQUID. DON'T USE NEAR FLAMES.

SAFETY WARNINGS

The following informations highlight the safety-related aspects linked to use. Reasonably foreseeable incorrect uses are also included:

- Carefully read the user manual before use
- Don't use the lamp if any part is broken or damaged
- Dispose of the broken or damaged lamp according to regulations in force.
- Hazardous toxic material 
- Don't ingest or inhale the oil in the container
- The lamp must be used exclusively by expert users and only in professional circumstances (the use by children is forbidden)
- Remove and dispose of any oil eventually spilled outside the container because of breakages and overturns.
- Hazardous flammable liquid 
- Don't use flames when the oil container is open or when it's being filled.